

HD CCTV DVR

QUICK START

■ 1080P Video Recording

Please read instructions thoroughly before operation and retain it for future reference.

For the actual display & operation, please refer to your DVR in hand.

Complete user manual download: www.surveillance-download.com/user/t204.swf

IMPORTANT SAFEGUARD

	CAUTION RISK OF ELECTRIC SHOCK	
CAUTION: To reduce the risk of electric shock, do not expose this apparatus to rain or moisture. Only operate this apparatus from the type of power source indicated on the label. The company shall not be liable for any damages arising out of any improper use, even if we have been advised of the possibility of such damages.		



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.



All lead-free products offered by the company comply with the requirements of the European law on the Restriction of Hazardous Substances (RoHS) directive, which means our manufacture processes and products are strictly “lead-free” and without the hazardous substances cited in the directive.



The crossed-out wheeled bin mark symbolizes that within the European Union the product must be collected separately at the product end-of-life. This applies to your product and any peripherals marked with this symbol. Do not dispose of these products as unsorted municipal waste. Contact your local dealer for procedures for recycling this equipment.



This apparatus is manufactured to comply with the radio interference requirements.

Federal Communications Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Trademark Acknowledgements



(EagleEyes) - The trademark application is filed and under process in the U.S. and other countries.

iPhone®, iPad® and iOS® are the registered trademark of Apple Inc., and Apple holds the intelligential property rights to the iPhone, iPad and iOS content.

Microsoft®, Windows®, Internet Explorer®, Google Chrome™ & QuickTime® mentioned in this document are the registered trademarks of their respective holders.

Disclaimer

The information in this manual was current when released. We reserve the right to revise or remove any content in this manual at any time. We do not warrant or assume any legal liability or responsibility for the accuracy, completeness, or usefulness of this manual. For the actual display & operation, please refer to your DVR in hand. The content of this manual is subject to change without notice.

Grounding

This is a Safety Class 1 Product (provided with a protective earthing ground incorporated in the power cord). The mains plug shall only be inserted in a socket outlet provided with a protective earth contact. Any interruption of the protective conductor inside or outside of the instrument is likely to make the instrument dangerous. Intentional interruption is prohibited.

Water & Moisture

Do not expose this product to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the product.

MPEG4 Licensing

THIS PRODUCT IS LICENSED UNDER THE MPEG-4 VISUAL PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER FOR (i) ENCODING VIDEO IN COMPLIANCE WITH THE MPEG-4 VISUAL STANDARD ("MPEG-4 VIDEO") AND/OR (ii) DECODING MPEG-4 VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NON-COMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED BY MPEG LA TO PROVIDE MPEG-4 VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION INCLUDING THAT RELATING TO PROMOTIONAL INTERNAL AND COMMERCIAL USES AND LICENSING MAY BE OBTAINED FROM MPEG LA, LLC. SEE [HTTP://WWW.MPEGLA.COM](http://WWW.MPEGLA.COM).

GPL Licensing



This product contains codes which are developed by Third-Party-Companies and which are subject to the GNU General Public License ("GPL") or the GNU Lesser Public License ("LGPL").

The GPL Code used in this product is released without warranty and is subject to the copyright of the corresponding author.

Further source codes which are subject to the GPL-licenses are available upon request.

We are pleased to provide our modifications to the Linux Kernel, as well as a few new commands, and some tools to get you into the code. The codes are provided on the FTP site, and please download them from the following site or you can refer to your distributor:

<http://download.dvrtw.com.tw/GPL/DVR/GM8210/linux-3.3-fa.tgz>

TABLE OF CONTENTS

1. CONNECTION	1
1.1 SATA Hard Disk Installation.....	1
1.2 Camera Connection	3
1.2.1 Normal / Motorized Lens Camera	3
1.2.2 Speed Dome Camera	4
1.3 External Device Connection.....	5
1.4 DVR Power On	5
2. FOR INITIAL USE.....	7
2.1 Setup Wizard	7
2.2 Clear Hard Disk.....	9
2.3 Change User Name and Password.....	10
3. USER INTERFACE.....	11
3.1 DVR Access	11
3.2 Live Page	11
3.1.1 DVR Status	11
3.1.2 Channel Status	12
3.1.3 Record-related Icons	12
3.3 Quick Menu Bar	12
3.4 Main Menu	13
4. HARDWARE OVERVIEW.....	15
4.1 Package Content	15
4.2 Front Panel	15
4.3 Rear Panel	16
5. FREQUENTLY-USED FUNCTIONS.....	19
5.1 Key Lock / Unlock	19
5.2 User Level Creation	19
5.3 PTZ Control.....	20
5.4 Playback	22
5.4.1 Playback Control.....	22
5.4.2 Event Search	22
5.4.3 Audio Playback	23
5.5 Video Backup	23
5.6 Video Playback on PC (.dv5)	24
5.6.1 Convert the file format to AVI	24
5.7 Digital Zoom.....	24
6. REMOTE OPERATION.....	25
6.1 Web Browser	25
6.1.1 IVS Statistics.....	27
6.1.2 PTZ Panel.....	28
6.2 Mobile Devices.....	29
6.2.1 Prerequisites	29
6.2.2 Where to download	29
6.2.3 Manual Setup	29
APPENDIX 1 PUSH VIDEO CONFIGURATION	31
A1.1 Alarm Sensor Connection	31
A1.2 Configuration	32

APPENDIX 2 SET PUSH VIDEO.....	33
A2.1 Prerequisite	33
A2.2 Enable Push Video	34
A3.2.1 From iOS Mobile Device (iPhone / iPad).....	34
A2.2.2 From Android Mobile Device	35
APPENDIX 3 COMPATIBLE USB FLASH DRIVE LIST	36
APPENDIX 4 COMPATIBLE SATA HDD LIST	37
APPENDIX 5 MAIN MENU STRUCTURE.....	38
APPENDIX 6 EAZY NETWORKING	40
A6.1 Via EagleEyes on iOS / Android Device	40
A6.2 Via Internet Explorer on PC / Laptop.....	45
A7.3 Cloud Icons	49

1. CONNECTION

Before the DVR is powered on, make sure you have installed a hard disk, connected at least one camera and a HDMI monitor. For details, please refer to the following sections.

Note: The DVR is designed to automatically detect the video system of the connected cameras (NTSC or PAL). To make sure the system detection is correct, please check if the cameras are connected to the DVR and power-supplied before the DVR is powered on.

1.1 SATA Hard Disk Installation


At least a hard disk is necessary for the recorder to save video footage, and firmware upgrade might be failed if there's no hard disk installed in this recorder.

Either of the following two types of hard disk installation is applicable for your DVR model. Please check the instructions below to see which installation method is the right one for your DVR to install a hard disk.

➤ Type 1


Note: Here takes an 8CH model as an example of how to connect a hard disk to your device. To know how many hard disks could be installed, please refer to the specifications of your device.

Step1: Remove the top cover, and find the hard disk connector and bracket in the device.




Step2: Get a compatible hard disk. With the PCB side facing down, insert the hard disk to one of the hard disk connector.

Note: To use a green hard disk, use **ONLY** the hard disk designed especially for surveillance to ensure the device works properly.



Step3: Fasten the hard disk to the bracket by securing the screw on the bracket.




Step4: Replace the top cover and fasten the screws you loosened in Step1.

➤ Type 2


Note: Here takes an 8CH model as an example of how to connect a hard disk to your device. To know how many hard disks could be installed, please refer to the specifications of your device.

Step1: Remove the top cover, and find where to install a hard disk.




Step2: Get a compatible hard disk. With the PCB side facing down, find the screw holes on the DVR base, and place the hard disk in the DVR.

Note: To use a green hard disk, use **ONLY** the hard disk designed especially for surveillance to ensure the device works properly.



Step3: Align the screw holes on the DVR base and the hard disk. Then, fasten the hard disk o the DVR base with the supplied screws from the bottom side of the DVR.

Step4: Connect the data bus and power cable for the hard disk.



Step5: Replace the top cover and fasten the screws you loosened in Step1.

1.2 Camera Connection

Install the camera on the wall or ceiling based on your installation environment and camera type. For installation details, please refer to the user manual of your camera.

1.2.1 Normal / Motorized Lens Camera

1) Connecting to DVR video input

Connect the camera video output to the DVR video input port with a coaxial cable or RCA cable with a BNC connector.

2) Connecting to DVR audio input (Optional)

Connect the camera audio output to the DVR audio input port with a RCA cable.

3) Connecting to power

Connect the camera with indicated power supply and make sure it's power-supplied.

1.2.2 Speed Dome Camera

The following description is taking our brand's speed dome camera as an example.

Note: The RS485 wiring is not needed when your DVR and speed dome camera are both our HD CCTV series. If yes, please go to **STEP 5** directly for PTZ camera setting.

Note: Speed dome camera connection for non-HD CCTV series is available only for selected DVR models.

STEP 1: Get a RJ11 cable with the proper length to your connection.

Different RJ11 connector may have different wire layout, so the connection might be different. If you cannot control the DVR after connection, please reverse the RJ11 cable connection with the DVR.

STEP 2: Remove one end of the insulating coating of the RJ11 cable.

Remove one end of the insulating coating of the RJ11 cable to find the RS485-A and the RS485-B wires, and remove the insulating coating to reveal the naked wires for further connection.

STEP 3: Twist the RS485-A and RS485-B wires of the RJ11 cable and the speed dome camera together.

Twist the RS485-A (red) and RS485-B (green) wires of the RJ11 cable to the RS485-A (brown) and RS485-B (orange) wires of the speed dome camera. To protect the naked wires, use the insulation tape to cover on the twisted wires.

STEP 4: Connect the other end of the RJ11 cable to DVR.

Solder the RS485-A (red) and RS485-B (green) wires of the RJ11 cable to the corresponding pins on the DVR rear panel.

STEP 5: Set the camera at the DVR side.

Right click to show the main menu in the live view, and go to “” (ADVANCED CONFIG) → “DEVICES” to set the camera.

- a) Select the device to “PTZ”.
- b) Set the ID to the value the same as the one set in the camera. The default ID of the camera is 000.
- c) Select the protocol to “NORMAL”.
- d) Set the baud rate to the value the same as the one set in the camera. The default baud rate of the camera is 2400.

ADVANCED CONFIG																								
CAMERA DETECTION ALERT NETWORK DISPLAY RECORD DEVICES DCCS IVS NOTIFY	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%;">CH1</td> <td style="width: 10%;">CH2</td> <td style="width: 10%;">CH3</td> <td style="width: 10%;">CH4</td> </tr> <tr> <td>DEVICE</td> <td colspan="3">PTZ</td> </tr> <tr> <td>ID</td> <td colspan="3">000</td> </tr> <tr> <td>PROTOCOL</td> <td colspan="3">NORMAL</td> </tr> <tr> <td>RATE</td> <td colspan="3">2400</td> </tr> </table>				CH1	CH2	CH3	CH4	DEVICE	PTZ			ID	000			PROTOCOL	NORMAL			RATE	2400		
	CH1	CH2	CH3	CH4																				
DEVICE	PTZ																							
ID	000																							
PROTOCOL	NORMAL																							
RATE	2400																							
<input type="button" value="EXIT"/>																								

1.3 External Device Connection

Some DVR models support external device connection with RS485 and alarm I/O ports, allowing users to connect control devices such as a keyboard controller, or connect alarm devices such as a magnetic contact or buzzer.

Check the user manual of your external device to know which pin(s) should be used, and connect it to the corresponding pins on the DVR rear panel.

1.4 DVR Power On

This device should be operated only with the type of power source indicated on the manufacturer's label. Connect the indicated AC power cord to the power adapter, and plug into an electrical outlet.

If your device has a power switch on the rear panel, turn it to “—”. The power LED will be on. If your device doesn't have a power switch on its rear panel, the power is on once the power source is connected.

Note: Before the DVR is powered on, make sure (1) the cameras are connected and power-supplied for the detection of the camera video system to be correct, and (2) a HDMI monitor is connected to the DVR for correct video output detection.

Note: To ensure that your DVR works constantly and properly, it's recommended to use an UPS, Uninterruptible Power Supply (Optional), for continuously operation.

2. FOR INITIAL USE


For the first time to power on this device, you might be prompted to:

- Go through the setup wizard
- Clear hard disk
- Change default user name and password

2.1 Setup Wizard

The setup wizard is prompted to guide you finishing the most common settings you might need to do.

Note: It's okay to skip the wizard. You can configure the following settings later in their respective menus.



Choose “EaZy” (EaZy Networking) to directly go to the EaZy Networking setting page, and refer to “APPENDIX 6 EAZY NETWORKING” at page 40 for details.


Note: To configure network setup by using EaZy Networking later, please go to “QUICK START” → “EaZy”.

Or select “NEXT” to go to the next step.



Name the device. If you don't want to name the device, just skip to the next step.

Note: To name the device later, please go to “SYSTEM” → “SYSTEM INFO”.



Change the default user name and password. If you don't change the user name and password here, you're not able to go to the next step. This step is compulsory.

Note: To change or edit user name and passwords, please go to “SYSTEM” → “ACCOUNT”.

SETUP WIZARD	
DATE	2015/MAR/05
TIME	14:33:46
FORMAT	<input type="button" value="Y/M/D"/> <input checked="" type="button" value=""/>
GMT	<input type="button" value="GMT+08:00"/> <input checked="" type="button" value=""/>
<input type="button" value="SKIP"/> <input type="button" value="PREV"/> <input type="button" value="NEXT"/>	

Set the date and time.

If you don't want to set the date and time now, just skip to the next step. However, it's necessary to keep the date and time right to ensure the accuracy of the recorded data.

Note: To set the date and time later, please go to "QUICK START" → "TIME SETUP". When the date and time are changed, you'll be prompted to clear the hard disk(s). Select "YES" to erase the previous recorded data, or there might be data disorder and you wouldn't find the footage you need.

SETUP WIZARD	
NTP SERVER	Pool.ntp.org
SYNC PERIOD	<input type="button" value="OFF"/> <input checked="" type="button" value=""/>
<input type="button" value="SKIP"/> <input type="button" value="PREV"/> <input type="button" value="NEXT"/>	

Configure if you want to connect this device to an NTP server to get the right time online.

Note: To set the date and time later, please go to "QUICK START" → "TIME SETUP".

SETUP WIZARD	
NETWORK TYPE	<input type="button" value="STATIC"/> <input checked="" type="button" value=""/>
IP	192.168.1.10
GATEWAY	192.168.1.1
NETMASK	255.255.255.0
PRIMARY DNS	8.8.8.8
SECONDARY DNS	168.95.1.1
PORT	80
<input type="button" value="SKIP"/> <input type="button" value="PREV"/> <input type="button" value="NEXT"/>	

Configure network setup by using the traditional method. For details, please download www.surveillance-download.com/user/network_setup/network_setup_recorder.pdf.

Note: To configure network setup by using the traditional method later, please go to "ADVANCED CONFIG" → "NETWORK".

SETUP WIZARD	
SMTP SERVER	Smtp.gmail.com
PORT	465
MAIL FROM	manager@gmail.com
SSL ENCRYPTION	ON
VERIFY PASSWORD	ON
USER NAME	manager@gmail.com
PASSWORD	●●●●●
<input type="button" value="SKIP"/> <input type="button" value="PREV"/> <input type="button" value="NEXT"/>	

Configure event notifications by email.

Note: To configure email notifications later, please go to "ADVANCED CONFIG" → "NETWORK" -> "EMAIL".

SETUP WIZARD	
DDNS	ON
SYSTEM NAME	Eagleeyes ▼
HOST NAME	MAC000E533A3D
E-MAIL	
CURRENT HOST ADDRESS	MAC000E533A3D4A.ddns.eagleeyes.tw
SKIP	PREV NEXT

Enable DDNS if needed. For details, please download
www.surveillance-download.com/user/network_setup/network_setup_recorder.pdf.

Note: To enable the DDNS later, please go to "ADVANCED CONFIG" → "NETWORK" → "DDNS".

2.2 Clear Hard Disk

When this device is powered on, hard disk detection will be on, and you'll be prompted to clear the hard disk(s):

CLEAR HDD	
CLEAR HDD HDD0	
YES	NO

Please choose "YES" to clear the connected hard disk(s), or this device will not detect hard disks properly for video recording.

It might take some time to clear the connected hard disk(s). When it's done, you'll see the remaining hard disk capacity on the top right corner of the screen.

Note: It's necessary to clear hard disks in order to format the connected disks to the right format to save video data. The format used for this device can **NOT** be read directly on a PC. Please do not install the hard disk directly to a PC and try to copy the video data saved in the hard disk. The video data might be impaired.

To change later, right click to show the main menu, and select  (SYSTEM) → "SYSTEM INFO" → "CLEAR HDD". The DVR will reboot when hard disk data are cleared.

SYSTEM		
ACCOUNT	BAUD RATE	
TOOLS	2400 ▼	
SYSTEM INFO	HOST ID	
	000	
	R.E.T.R	
	5 ▼	
	AUTO KEY LOCK(S)	
	NEVER ▼	
	CLEAR HDD	
	HDD-0 ▼	
	RESET DEFAULT	
	SUBMIT	
	REMOTE CONTROL ID	
	000	
	DEVICE TITLE	
	OFFICE	
	SERIAL TYPE	RS485
	VIDEO FORMAT	NTSC
	VERSION	1019-1008-1010-1010
EXIT		

2.3 Change User Name and Password

It's highly recommended to change the user name and password of this device to keep your account safe. Otherwise, any person could access this device if he knows the default user name and password.

If you didn't go through the setting wizard at the first place, you'll be prompted to change the user name and password:

WARNING
PLEASE BE ADVISED TO MODIFY THE DEFAULT ACCOUNT TO ENSURE YOUR INFORMATION SECURITY.
<ul style="list-style-type: none"> <input checked="" type="radio"/> MODIFY <input type="radio"/> REMIND ME LATER <input type="radio"/> DON'T REMIND ME ANYMORE
CONFIRM

Choose "MODIFY" to start the change immediately.

To change later, right click to show the main menu, and select  (SYSTEM) → "ACCOUNT" to change the default user name and password of SUPERVISOR.

SYSTEM			
ACCOUNT			
TOOLS	USER LIST		
SYSTEM INFO	USER NAME	LEVEL	
BACKUP DATA	admin	SUPERVISOR	
BACKUP LOG			
REGULAR REPORT			
EXIT	ADD	EDIT	DEL

3. USER INTERFACE


3.1 DVR Access

Connect your USB mouse to one of the USB ports on the DVR front panel, and check if there's a mouse icon (💡) on the screen, indicating the USB mouse is detected properly.


Move your mouse to enter the DVR password with the password keypad. The default user name and password are both “admin”. The status will be changed from 🔒 (key lock) to 🚪 (unlock).

Note: You may configure four different user levels to have different access privileges in “SYSTEM” → “ACCOUNT”. For details, please refer to “5.2 User Level Creation” at page 19.

Password Input



3.2 Live Page



3.1.1 DVR Status

Note: Certain icons are for selected models only.

	Key lock		Key unlock
	Overwrite on		Overwrite off
	Internet disconnected		Internet connected
	Local connection		USB mouse connected
	USB flash drive / device connected		No USB device connected
	IVS on		
	Timer record on		Timer record off
	PTZ mode on		PTZ mode off
	Sequence mode on		Sequence mode off

3.1.2 Channel Status

Note: Certain icons are for selected models only.

	Live audio on		Audio off		Audio playback on		Audio playback off
	Recording		PTZ control		Motion event		Alarm event
	PIR event		Virtual fence event		One way pass event		Scene Change event

3.1.3 Record-related Icons

1) Manual Recording

By defaults, manual recording is on () when the DVR is powered on and a hard disk is installed.

2) Event Recording

The event icons, / / / / , show on the channel status bar when their respective events occur and the related record function is on.

3) Timer Recording

When timer recording is on, you will see "" on the screen.

4) HDD Overwritten


Be defaults, the HDD overwritten function is set to ON, and "" will be shown on the screen.

Note: To disable this function, right click to display the main menu in the live view, and go to "" (ADVANCED CONFIG.) → "RECORD" → "OVERWRITE".

3.3 Quick Menu Bar

Move to the arrow mark to extend the quick menu bar and show the five functions as follows:

Quick Menu: Open



Click to show the channel switch panel and select the channel you want.



Click to display the playback control panel, and click to play the latest recorded video clip, or click to enter the search list.



Switch to the channel you want first, and click to enter the zoom-in mode. In this mode, click and drag the red frame on the bottom left of the screen to move to the place you want to see. To exit this mode, click .




Click to show the power off panel to either halt or reboot the system.

3.4 Main Menu

Right-click anywhere on the screen to show the main menu as follows, and right-click again to exit.

Main Menu



QUICK START

Click to set the status display, image settings, and date & time.



SYSTEM

Click to set the system configurations.



EVENT INFORMATION

Click to enter the event search menu.



ADVANCED CONFIG

Click to set CAMERA, DETECTION, ALERT, NETWORK, DISPLAY, RECORD, DEVICES*, DCCS, IVS* and NOTIFY*.



SCHEDULE SETTING

Click to set timer for record, motion detection, alarm (in and out)*, Push Video*, and buzzer.

** For selected models only*

4. HARDWARE OVERVIEW

Note: The functions on the front panel and rear panel may vary, depending on the model you have.

4.1 Package Content

➤ Standard Package

- | | |
|---|--------------------------------------|
| <input type="checkbox"/> DVR | <input type="checkbox"/> HDD screws |
| <input type="checkbox"/> Adapter & power cord | <input type="checkbox"/> Quick Start |

➤ Optional Accessories

- | | |
|---|---|
| <input type="checkbox"/> I/O terminal block | <input type="checkbox"/> IR Remote Controller |
| <input type="checkbox"/> USB Mouse | |

4.2 Front Panel

1) LED Indicators

-  DVR is powered on.
-  The hard disk is reading or recording.
-  An alarm is triggered. (*For selected models only*)
-  Timer recording is on. (*For selected models only*)
-  Under playback status. (*For selected models only*)

2) CH1 ~ 16 / 1 ~ 8 / 1 ~ 4

Press the channel number buttons to select the channel to display.

3) 

Press to show the 4 channel display mode.

4) SEQ

Press to display each channel in full screen one by one starting from CH1. When the last channel is displayed, it will repeat from CH1 again. To exit this mode, press “SEQ” again.

5) SLOW

In the playback mode, press to show slow playback.

6) ZOOM

Press to enlarge the picture of selected channel in the FRAME or FIELD recording mode.

7) PLAY

Press to playback the latest recorded data.

8) LIST (Event List Search)

Press to quickly search the recorded files by event types, or select FULL to show all the event logs.

To quickly search the time you want, select “QUICK SEARCH”. For details, please refer to “5.4.2 Event Search” at page 22.

9) ENTER

Press “ENTER” to confirm the setting.

10) MENU

Press “MENU” to enter the main menu.

11) **▲ (II / PAUSE) / ▼ (■ / STOP) / ◀ (◀ / REW) / ▶ (▶ / FF)**

Press **▲** / **▼** / **◀** / **▶** to move up / down / left / right.

In the playback mode:

Press “**▲**” to pause playback.

Press “**▼**” to stop playback.

Press “**▶**” to fast forward.

Press “**◀**” to fast rewind.

12) **AUDIO (SLOW + ZOOM)**

Press “SLOW” + “ZOOM” to select live or playback audio from audio channel 1~4.

 Live audio from audio channel 1~4
(indicated in white).

 Playback audio from audio channel 1~4
(indicated in yellow).

 Audio channel unselected

13) **P.T.Z. (田 + SEQ)**

Press “**田**” + “SEQ” at the same time to enter / exit the PTZ control mode.

14) **USB port**

There are two USB ports on the front panel, one for connecting your USB mouse for mouse control, and the other one for connecting your USB flash drive for video backup.

Note: It's not allowed to have two USB mice or two USB flash drives connected on the front panel.

Note: For the compatible USB flash drive list, please refer to “APPENDIX 3 COMPATIBLE USB FLASH DRIVE LIST” at page 36.

4.3 Rear Panel

1) **VIDEO IN**: Connect to the video connector of a camera.

Note: The DVR will automatically detect the video system of the camera, please make sure that the cameras are properly connected to the DVR and power-supplied before the DVR is turned on.

2) **AUDIO IN**

Connect to the audio connector of a camera if the camera supports audio recording.

Note: To make a video backup with audio, make sure the camera which supports the audio function is connected to the video-in channel and audio-in channel. For example, the audio data from audio CH1 will be recorded with the video data from video CH1.

For 16CH models, the audio CH1 ~ CH4 are corresponding to video CH1 ~ CH4 respectively.

3) **AUDIO OUT**

Connect to a speaker with 1 mono audio output.

4) **HDMI**

Connect to the HDMI port of the monitor which supports HDMI video output.

Note: Dual video outputs via both VGA and HDMI ports are supported.

5) **VGA**

Connect to the VGA port of the monitor which supports VGA video output.

Note: Dual video outputs via both VGA and HDMI ports are supported.

6) **IR (For selected models only)**

Connect the IR receiver extension line for remote control.

7) **eSATA (For selected models only)**

This port is used to connect a storage device supporting eSATA interface; for instance, an external hard disk or a disk array.

Note: Please purchase a disk array supporting Linux system to ensure your DVR to work properly.

Note: If the disk array is not connected or detected well, check the mode of your disk array, or do a reset default on your disk array and try again.

8) EXTERNAL I/O (*For selected models only*)

This port is used to connect external devices (such as speed dome cameras or external alarm, etc).

9) LAN

Connect to Internet by LAN cable.

10) DC IN

Connect to the supplied adapter.

11) VIDEO OUT

Connect to a CRT monitor for main monitor output.

12) Power Switch (*For selected models only*)

Switch to “I” to turn on the power, and “O” to turn off the power.

5. FREQUENTLY-USED FUNCTIONS

5.1 Key Lock / Unlock

To lock or unlock local operation, click  (unlock) or  (lock) on the DVR status bar to change the status to  (lock) or  (unlock).

To unlock local operation, you'll be prompted to enter the user name and password to access.

Note: The default user name and password are both "admin", which is the highest user level.

Note: Different user level has different access privilege for certain DVR functions. Please refer to "5.2 User Level Creation" at page 19.

5.2 User Level Creation

Note: This function is available only for "SUPERVISOR".

To create different user account for different access privilege, click  (SYSTEM), and select "ACCOUNT" to enter "USER LIST".

SYSTEM					
ACCOUNT		USER LIST			
TOOLS		USER NAME	LEVEL		
SYSTEM INFO		admin	SUPERVISOR		
BACKUP DATA		power	POWER USER		
BACKUP LOG		normal	NORMAL		
REGULAR REPORT		guest	GUEST		
EXIT		ADD	EDIT	DEL	

Different user level has different access privilege for certain functions as described below:

	Function	User Level			
		SUPERVISOR	POWER	NORMAL	GUEST
■ DVR status					
 / 	Key lock / unlock	✓	✓	✓	✓
■ Channel status					
 / 	Live audio on / off	✓			
 / 	Playback audio on / off	✓			
	PTZ Control	✓	✓		
■ Quick menu bar					
	Channel Selection	✓	✓	✓	
	Playback	✓	✓		
	Digital Zoom	✓	✓	✓	✓
	Power	✓			

	Function	User Level			
		SUPERVISOR	POWER	NORMAL	GUEST
■ Main menu					
	Quick Start	✓			
	System	✓			
	Event Information	✓			
	Advanced Config.	✓			
	Schedule Setting	✓			
■ Playback control					
	Fast Forward	✓	✓		
	Fast Rewind	✓	✓		
	Play / Pause	✓	✓		
	Stop	✓	✓		
	Slow Playback	✓	✓		
	Previous / Next Hour	✓	✓		
	Quick Search	✓	✓		

5.3 PTZ Control

Note: This function is available only for "SUPERVISOR" and "POWER USER". To know more details, please refer to "5.2 User Level Creation" at page 19.

Note: For our brand's HD CCTV motorized camera series, click might only show specific icons for focal length and focus adjustment. For details, please refer to its own user manual.

In the full view

In the split view, click the channel you want to switch to the full screen mode, and click to show the PTZ control panel.



	Camera Menu	Click to enter the camera main menu. For details about each camera menu, please refer to its own user manual.
	Enter	Click to confirm your selection / enter the menu.
	Up / Down / Left / Right	Click the arrow keys (\blacktriangle / \blacktriangledown / \blacktriangleleft / \blacktriangleright) to move the camera lens up / down / left / right.
	Iris + / Iris -	This two buttons are designed for the PTZ camera which uses Pelco-D to control. To know the actions after clicking Iris + and Iris -, please refer to the camera's user manual.

	Zoom in / out max	Click to zoom in on the image to the largest / zoom out on the image to its original size.
	Zoom in / out	Click to zoom in / out the image.
	Focus near / far	Click to adjust the focus of the image.
	Auto mode	Click to activate the auto function. Before using it, you need to assign a specific function that will be enabled when "Auto mode" is clicked. For details, please refer to the user manual of the camera.
	Preset point	Click to enter the PTZ preset point you want to see.
	Auto tracking	Click to start auto tracking when your speed dome camera supports this function.
	Manual Focus	This function is used to memorize the focus parameters you've made after you use to manually adjust the focal length and focus. The next time when you move to the same focal length, the camera will use the parameters as the ones for Auto Focus.
	Auto Focus	Click to automatically adjust the focus of the camera.


In the split view

Click on the channel status bar to display the panel as follows:

		Up / Down / Left / Right	Click to move your selection up / down / left / right, or change settings.
		Digital zoom in / out	Click to zoom in / out the camera image digitally.
		Focus near / far	Click to adjust the focus of the image.
		Preset point	Click to display the preset point panel for preset point viewing or setting. For details, please refer to the section below.

How to set a preset point:

Step1:




Step2: Click or to the proper ratio you need, and click to move to the point you want to configure as a preset point.

Step3: Click the numbering you want to configure for this point, and wait till you see (command sending) appearing and disappearing on the DVR status bar.

Step4: Repeat from Step1 again to set other points if needed, or click to return to the preset point selection panel.

How to go to a preset point:

Step1:




Step2: Select the numbering within which saves the camera view you want to see, and wait till you see (command sending) appearing and disappearing on the DVR status bar.

5.4 Playback

Note: This function is *NOT* available for "GUEST". Please refer to "5.2 User Level Creation" at page 19.

Click on the quick menu bar to display the playback control panel, and click to play the latest recorded video clip, or click to enter the search list.



Note: There must be at least 8192 images of recorded data for playback to work properly. If not, the device will stop playback. For example, if the IPS is set to 30, the recording time should be at least 273 seconds (8192 images / 30 IPS) for the playback to work properly.

5.4.1 Playback Control

	Fast Forward	Increase the speed for fast forward. Click once to get 4X speed forward and click twice to get 8X speed, etc., and the maximum speed is 32X.
	Fast Rewind	Increase the speed for fast rewind. Click once to get 4X speed rewind and click twice to get 8X speed, etc., and the maximum speed is 32X.
	Play / Pause	Click to play the latest recorded video clip immediately, and click again to pause. In the pause mode, click once to get one frame forward, and click to get one frame rewind.
	Stop	Click to stop the video playback.
	Slow Playback	Click once to get 1/4X speed playback, and click twice to get 1/8X speed playback.
	Previous / Next Hour	Click to jump to the next / previous time interval in an hour, for example, 11:00 ~ 12:00 or 14:00 ~ 15:00, and start playing the earliest event video clip recorded during this whole hour.
	Repeat	Click to set point A and point B in a video clip, and the system will play only the specified range in that clip.
	Backup	Click to open the backup menu for video backup.

5.4.2 Event Search

Click to quickly search the recorded files by event types, or select FULL to show all the event logs.
To quickly search the time you want, select "QUICK SEARCH".

5.4.3 Audio Playback

In the playback mode, click  or  on the channel status bar to play or mute audio recording.

Note: To make a video backup with audio, or play a recording with audio, make sure the camera which supports the audio function is connected to the video-in channel and audio-in channel. For example, the audio data from audio CH1 will be recorded with the video data from video CH1. For 16CH models, the audio CH1 ~ CH4 are corresponding to video CH1 ~ CH4 respectively.

5.5 Video Backup

Note: This function is available for "SUPERVISOR". For details, please refer to "5.2 User Level Creation" at page 19.

Note: Before using the USB flash drive, please use your PC to format the USB flash drive to FAT32 format first. For the list of compatible USB flash drives, please refer to "APPENDIX 3 COMPATIBLE USB FLASH DRIVE LIST" at page 36.

Note: Video backup could be made via a USB flash drive or the Internet. It's **NOT** allowed to connect the hard disk to your PC directly for it may impair the recorded data saved in the hard disk.

To copy video data for video backup, click  (SYSTEM), and select "BACKUP DATA".

SYSTEM		
ACCOUNT	START DATE	2009/NOV/19
TOOLS	START TIME	08:30:21
SYSTEM INFO	END DATE	2009/NOV/19
BACKUP DATA	END TIME	17:59:29
BACKUP LOG	CHANNEL	<div style="border: 1px solid black; padding: 2px;"> <input type="checkbox"/> ALL <input checked="" type="checkbox"/> CH1 <input checked="" type="checkbox"/> CH2 <input checked="" type="checkbox"/> CH3 <input type="checkbox"/> CH4 <input type="checkbox"/> CH5 </div>
REGULAR REPORT	HARD DISK	<div style="border: 1px solid black; padding: 2px;">ALL HDD</div>
	OUTPUT FILE FORMAT	AVI
	TARGET DEVICE	USB DEVICE
	BACKUP	SUBMIT
	REQUIRE SIZE: 554MB	SUBMIT
EXIT	AVAILABLE SIZE: 3788.0MB	

Step1: Select the time within which includes the video data you want to backup.

Step2: Select the channel(s) within which includes the video data you want to backup.

Step3: In "OUTPUT FILE FORMAT", select the output video format: DEFAULT / AVI.

- When "DEFAULT" is selected, the footage is saved to ".dv5", and you can only open it with our own video player on PC. For details, please check "5.6 Video Playback on PC (.dv5)".

Note: It's recommended to save the file to the default format for security reasons. Only specific video player supports the default format and not everyone can see the video footage.

- When "AVI" is selected, the footage will be converted to "avi", and you can open it with any media player which supports the "avi" format on PC.

Step4: In "TRAGET DEVICE", select "USB DEVICE" for video backup.

Step5: In “REQUIRE SIZE”, select “SUBMIT” to know the file size of the selected footage.

Step6: In “BACKUP”, select “SUBMIT” to start copying footage to your USB flash drive, and wait till the backup successful message appears.

5.6 Video Playback on PC (.dv5)

For video backup with the format “.dv5”, you can only use our own player to play.

Note: It's **NOT** allowed to remove the hard disk installed in the DVR and connect it directly to your PC to check recorded video clips. It might impair the files saved in the hark disk, causing the loss of those files even when the disk is replaced back to the DVR.

To play “.dv5” video on your PC:

Step1: Insert the USB flash drive with recorded data into your PC.

Note: The supported PC operating systems are Windows 8, Windows 7, Windows Vista & Windows XP.

Step2: Find the program “PLAYER.EXE” in the USB flash drive, and double-click it to install.

Note: “PLAYER.EXE” can also be downloaded from www.surveillance-download.com/user/t204.swf.

Step3: Run the program, *VideoPlayer*, and browse to where you save the recorded data.

Step4: Select the file you want to start video playback

5.6.1 Convert the file format to AVI

To convert the video file format to AVI, click “AVI” from the playback panel to start file conversion.

Note: The recorded audio (if any) will be removed when the file format is converted to AVI.


Note: If he footage includes data for multiple channels, click to a specific channel for this function to work properly.



5.7 Digital Zoom

Switch to the channel you want to zoom in, and move to the left side of the screen to show the quick start bar.

Click to enter the zoom-in mode. In this mode, click and drag the red frame on the bottom left of the screen to move to the place you want to see.



To exit this mode, right-click anywhere on the screen.

Note: You need to exit the zoom mode first to use other DVR functions.

6. REMOTE OPERATION

6.1 Web Browser

You can view the images or operate your DVR with a web browser, for example, Microsoft Internet Explorer.

Note: The supported PC operation systems are Windows 8, Windows 7, Windows Vista & Windows XP.

Note: To use Mozilla Firefox or Google Chrome for remote access, please go to Apple's official website (<http://www.apple.com>) to download and install QuickTime first.

Note: The illustration below is just for your reference and may be different from what you actually see. Some functions and buttons are for selected models or certain user levels only.


Step 1: Key in the IP address used by this device in the URL address box, such as 60.121.46.236, and press Enter. You will be prompted to enter the user name and password to access the device.

If the port number this device used is NOT 80, you need to key in the port number additionally. The format is **ipaddress:portnum**.

For example, for the IP address 60.121.46.236 and port No. 888, please key in "http://60.121.46.236:888" into the URL address box, and press "Enter".

Step 2: Enter the user name and password, and click "OK". You will see a similar screen as the following when the login information is correct.

Note: The default user name and password for remote access are both "**admin**".



Icon	Description
	Click to go to the live view of the DVR.
	Click to go to the detailed DVR setting.
	Click to enter the PTZ mode. This function is also used for our band's HD CCTV motorized camera series to adjust its focal length and focus remotely. For details, please refer to "6.1.2 PTZ Panel" at page 28.
Video / Audio Control	
Format	H.264 / QuickTime QuickTime is Apple Inc.'s multimedia software. You need to have QuickTime installed in your operation system first. When "QuickTime" is selected, you will be prompted to enter the user name and password to access the server of the DVR.
Quality	BEST / HIGH / NORMAL / BASIC Select the image quality.

Icon	Description
Sub Stream Resolution	<p>4 CIF / CIF Select the sub stream resolution (4CIF: 704*480 / CIF: 352*240) for live display.</p>
Audio	<p>Select the audio channel you want for listening to the live audio. Note: Your camera must support audio recording, and connect to the video channel which supports audio recording and the audio input of the DVR. For details, please refer to "4.3 Rear Panel" at page 16.</p> <p> means mute. To disable the mute status, click this icon again and select the audio channel you want.</p>
Streaming	<p>This function shows only when a single channel is selected. Choose the stream resolution for live display.</p> <p>When "Sub Steam" is selected, the resolution will be the one selected in "Sub Stream Resolution"; When "Recording" is selected, the resolution will be the one selected in " -> "DVR" -> "Record". -> "Manual".</p>
Cache Time	<p>Select the cache time from 0 ~ 800ms. The higher the value, the more time it's going to be needed to wait for the image to show, but the better the image quality will be.</p>
Channel Control	
Channel Selection (1 ~ 16 / 1 ~ 8 / 1 ~ 4)	Click one of the number to switch to the channel you want to see in full screen.
 / 	Click to go to the previous / next channel, or change setting.
	Click to take a snapshot of the current view, and save it to the specified path in your PC set in "  -> "General".
 / 	<p> Click to display each channel one by one, starting from CH1. When the last channel is displayed, it will start from CH1 again.</p> <p> To exit from this display mode, press any other channel display button.</p>
 /  / 	Click to show 4-cut / 9-cut / 16-cut display.
	Click to enable local desktop display remotely. An individual window will pop up to show the local view. All operations available at the local side could be done independently and remotely in this window.
	Click to switch the display to full screen.
Event Search & Playback	
	Increase the speed for fast rewind. Click once to get 4X speed rewind and click twice to get 8X speed, etc., and the maximum speed is 32X.
	Increase the speed for fast forward. Click once to get 4X speed forward and click twice to get 8X speed, etc., and the maximum speed is 32X.
	Click to play the current video clip.
	Click to pause the video playback.
	Click to stop the video playback.
	Click to play the video clip slowly, once to get 4X slower, twice get 8X slower.
	Click to enter the record list and search and footage you need.
	Click to enter the backup menu and copy the footage you need to your PC. Note: To play the backup file (.avc), go to "  -> "General" -> "Configure", and download the player to install.
IVS Panel*	
	This button is enabled only when the IVS mode is enabled. Click to show the detection line.
	Click to enter the IVS statistics page. For details, please refer to "6.1.1 IVS Statistics" at page 27.

* For selected models only

6.1.1 IVS Statistics

Note: This function is for selected models only.

The screenshot displays the IVS Statistics interface, which includes the following components:

- H.264 DVR**: A panel on the left showing settings for Format (H.264), Quality (BEST), Resolution (CIF), and Audio (1). It also lists four channels (CH1, CH2, CH3, CH4) with IN and OUT counts (all 0). Below these are several control icons.
- Live View**: A large video preview window showing an office interior. The video header indicates FR:12.00 fps DR:338 kbps DATE TIME: 2014/10/29 16:06:02. The preview is labeled "CH1".
- IVS Statistics**: A link pointing to the Event Search Panel.
- IVS Statistics: Event Search Panel**: A dialog box for searching events. It has checkboxes for Channel (1 checked, 2, 3, 4 unchecked), Event (Alarm checked, Motion, Inflow, Outflow, Virtual Fence, Oneway, Human Detection all unchecked), and search fields for HDD No. (HDD-0) and Date (2014/11/07). A "Search" button is present.
- IVS Statistics: List**: A table showing event counts by hour. The table has two columns: Hour and Count. The data is as follows:

Hour	Count
2014 / 11 / 07 00:00 - 01:00	0
2014 / 11 / 07 01:00 - 02:00	0
2014 / 11 / 07 02:00 - 03:00	0
2014 / 11 / 07 03:00 - 04:00	0
2014 / 11 / 07 04:00 - 05:00	0
2014 / 11 / 07 05:00 - 06:00	0
2014 / 11 / 07 06:00 - 07:00	0
2014 / 11 / 07 07:00 - 08:00	0
2014 / 11 / 07 08:00 - 09:00	0
2014 / 11 / 07 09:00 - 10:00	0


Buttons for "Backup" and "Day" are at the bottom.

- IVS Statistics: Chart**: A bar chart showing event counts by hour. The Y-axis is "Count" (0 to 90) and the X-axis is "Hour" (0 to 23). The bars show a peak around hour 15 (approx. 80) and a dip around hour 20 (approx. 15).

Buttons for "Backup" and "Day" are at the bottom.

6.1.2 PTZ Panel

Note: This function is for selected models only.



Function	Description
	Click to enter the camera main menu. For details about each camera menu, please refer to its own user manual.
	Click the arrow keys (\blacktriangle / \blacktriangledown / \blackleftarrow / \blackrightarrow) to move the camera lens up / down / left / right.
PTZ Channel	Select the channel which connects the PTZ camera or our brand's HD CCTV motorized camera you want to control.
Preset	Click on the preset point numbering to which you want your camera to move.
	Click to adjust the focus of the image.
	Click to zoom in / out the image.
	Click to zoom in on the image to the largest / zoom out on the image to its original size.
	Click to start auto tracking when your speed dome camera supports this function.
	Click to take a snapshot of the current view, and save it to the specified path in your PC set in " " → "General".
	Click to activate the auto function. Before using it, you need to assign a specific function that will be enabled when "" is clicked. For details, please refer to the user manual of your PTZ camera or our brand's HD CCTV motorized camera.

6.2 Mobile Devices

Note: For more details about mobile surveillance via your mobile device, download the instructions of EagleEyes installation and configuration from www.surveillance-download.com/user/eagleeyes_quick.pdf.

EagleEyes is a mobile phone program used with our surveillance system for remote surveillance. It has several advantages:

- It's free (Except *EagleEyes Plus* for iPhone, *EagleEyes Plus+* for Android, and *EagleEyesHD Plus* for iPad).
- It's compatible with several popular mobile platforms, such as iOS and Android.

6.2.1 Prerequisites

Before installing *EagleEyes* to your mobile device for remote surveillance, make sure you have checked the following:

- ✓ Your mobile platform is iOS or Android.
- ✓ Mobile Internet services are subscribed and available to use for your mobile device.

Note: You might be charged for Internet access via the wireless or 3G network. For the Internet access rate details, please check with your local network operator or service provider.

- ✓ You have noted down the IP address, port number, user name and password used to access your network camera from Internet.

6.2.2 Where to download

- For iOS users, please go to "App Store", and search "EagleEyes" to download.
- For Android users, please go to "Play Store", and search "EagleEyes" to download.


When the download is completed, *EagleEyes* will be installed automatically to the location where all applications are saved in your phone by default, or where you specify.

6.2.3 Manual Setup

Note: To know how to configure by EaZy Networking, please refer to "APPENDIX 6 EAZY NETWORKING" at page 40.


Step1: Open *EagleEyes* to go to the address book.

Step2: Then, click "+", and select "Manual" to go to the setting page.




Step3: In the setting page, enter all the information needed to access this device in the “REQUIRED” column, and click “Get Type” to examine if the information you entered is correct. The device type will be detected properly.

Step4: (Optional) Configure the settings in the “OPTIONAL” column as needed.



Step5: Click “Save” to return to the address book. Enable “Guard” to receive Push Video / Push Status.

Note: Push Video / Push Status is for selected models only. Before enabling Guard, please make sure if your device supports this function.



Step6: Click on the item you just added in the address book to access and check the live view.


APPENDIX 1 PUSH VIDEO CONFIGURATION

Note: This function is for selected models only.

A1.1 Alarm Sensor Connection

Connect the alarm sensor, such as magnetic contacts, to the alarm-in port on the DVR rear panel. Alarm-in 1 corresponds to video channel 1, alarm-in 2 corresponds to video channel 2, and so on.

Note: The voltage restriction for alarm-in device connection is under DC24V 1A.



A1.2 Configuration

Before configuring Push Video, make sure:

1. The DVR system is set up as described in "1. CONNECTION" at page 1.
2. The DVR is connected to Internet.
3. You've installed the app, EagleEyes, on your iOS or Android mobile devices.
For details, please refer to "6.2 Mobile Devices" at page 29.

Step1: Right click to show the main menu.

Go to (ADVANCED CONFIG.) → "NOTIFY". In PUSH VIDEO, select the alarm device you want, and configure the alarm type.

ADVANCED CONFIG																	
<p>CAMERA DETECTION ALERT NETWORK DISPLAY RECORD DEVICES DCCS IVS NOTIFY</p>	<p>PUSH VIDEO PUSH STATUS MESSAGE MAIL VIDEO MAIL VIDEO FTP</p>	<p>RESET ALL GUARD CONNECTION</p> <p>ALARM TRIGGERED DEVICE</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>CH01</td><td>ALARM OFF / INTERNAL ALARM</td><td style="width: 20px;"></td></tr> <tr><td>CH02</td><td>ALARM OFF</td><td></td></tr> <tr><td>CH03</td><td>ALARM N.O.</td><td></td></tr> <tr><td>CH04</td><td>ALARM OFF</td><td></td></tr> </table> <p>SUBMIT</p> <p>ALARM IN 1 ▾</p> <p>CH1 CH2 office CH4</p>				CH01	ALARM OFF / INTERNAL ALARM		CH02	ALARM OFF		CH03	ALARM N.O.		CH04	ALARM OFF	
CH01	ALARM OFF / INTERNAL ALARM																
CH02	ALARM OFF																
CH03	ALARM N.O.																
CH04	ALARM OFF																
EXIT																	


Step2: Open EagleEyes, and add this DVR to the EagleEyes address book.

Step3: Enable Push Video as described below, and try to trigger your sensor to see if you can receive Push Video successfully.

① Enable Push Video.



② Trigger the input alarm.



③ Receive an event notification and see video.



APPENDIX 2 SET PUSH VIDEO


This DVR series supports instant event notifications to your iOS / Android mobile device with our self-developed program, "EagleEyes", installed. When a man is detected by an external alarm device, the DVR will immediately receive alarm signals and send to your iOS / Android mobile device.

Note: iOS and Android are the trademarks or registered trademarks of their respective holders.

1 Enable Push Video.



2 Trigger the input alarm.



3 Receive an event notification and see video.



A2.1 Prerequisite


Before setting this function, make sure you have checked the following:

- ✓ You have an iOS or Android mobile device with our self-developed program, "EagleEyes", installed. For details, please refer to the previous chapter.
- ✓ An external alarm device is connected to the external I/O ports on the rear panel. Make sure a camera is also connected to record for alarm occurrences. To know which video channel corresponds to which alarm pin, please refer to "APPENDIX 1 PUSH VIDEO CONFIGURATION" at page 31.
- ✓ The event record function of your DVR is not disabled.
- ✓ The motion detection function of your DVR is not disabled.
- ✓ Your DVR is connected to Internet. For details, please refer to http://www.surveillance-download.com/user/network_setup/network_setup_recorder.pdf.

A2.2 Enable Push Video


A3.2.1 From iOS Mobile Device (iPhone / iPad)

Step1: In the iPhone / iPad main menu, select “Settings” → “Notifications”. Select “EagleEyes”, and make sure the notification is set to on.




Step2: Open “EagleEyes”, and switch “Guard” to “ON”. You’ll receive the message indicating that Push Video is on.

Step3: Return to the main page or standby page of iPhone / iPad. You’ll receive event notifications when there’s an alarm event. Follow the on-screen instruction to immediately play the recorded clip.



A2.2.2 From Android Mobile Device

In the address book, switch “Guard” from “OFF” to “ON”.



APPENDIX 3 COMPATIBLE USB FLASH DRIVE LIST

Please upgrade the firmware of the DVR to the latest version to ensure the accuracy of the following table. If the USB flash drive is not supported by the DVR, you will see  on the screen.

Note: Please use your PC to format the USB flash drive as "FAT32".

Note: You can backup up to 2GB video data for one-time USB backup. To backup more data, please set the time & channel(s) you want, and start USB backup again.

MANUFACTURER	MODEL	CAPACITY
Transcend	JFV35	4GB
	JFV30	8GB
Kingston	DataTraveler	1GB
PQI	U172P	4GB
Apacer	AH320	2GB
	AH320A	8GB
	AH220	1GB
	AH320	4GB
A-data	RB-18	1GB
Sandisk	Cruzer Micro	2GB
	Cruzer Micro	4GB
	Cruzer4-pk	2GB
Netac	U208	1GB
MSI	F200	4GB
SONY	Micro Vault Tiny 2GB	2GB
	Micro Vault Tiny 4GB	4GB
	Micro Vault Tiny	1GB

APPENDIX 4 COMPATIBLE SATA HDD LIST

Please upgrade the firmware of the device to the latest version to ensure the accuracy of the following table.

Note: It's necessary to install a hard disk first before firmware upgrade to ensure the upgrade process works properly.

Note: To use a green hard disk, use ONLY the hard disk designed especially for surveillance to ensure the device works properly.

Seagate*			
MODEL	CAPACITY	MODEL	CAPACITY
Pipeline HD ST3500312CS	500GB	ST2000DM001	2TB
Pipeline HD ST500VT000	500GB	ST2000VX004	2TB
Pipeline HD ST1000VM002	1TB	ST3000VM002	3TB
Pipeline HD ST1000VM002	1TB	ST3000VX004	3TB
ST31000525SV	1TB	ST3000VX000	3TB
ST31000340AS	1TB	ST4000VM000	4TB
ST1000VX002	1TB	ST4000VX002	4TB
ST2000VX000	2TB		
WD			
MODEL	CAPACITY	MODEL	CAPACITY
WD10PURX	1TB	WD30PURX	3TB
WD20PURX	2TB	WD30EURX	3TB
WD20EURS	2TB	WD30EFRX	3TB
WD20EURX	2TB	WD40PURX	4TB
WD20EFRX	2TB	WD40EURX	4TB
WD2002FAEX	2TB	WD60EURX	6TB
TOSHIBA			
MODEL	CAPACITY	MODEL	CAPACITY
DT01ACA050	500GB	DT01ABA200V	2TB
DT01ABA050V	500GB	DT01ACA200	2TB
DT01ABA100V	1TB	MD03ACA300V	3TB
DT01ACA100	1TB	DT01ACA300	3TB
MD03ACA200V	2TB	MD03ACA400V	4TB

* To know more details about SRS and its related support and service, please contact your local Seagate representative directly.

APPENDIX 5 MAIN MENU STRUCTURE

	QUICK START	GENERAL	CHANNEL TITLE
			EVENT STATUS
			DATE DISPLAY
			DCCS DISPLAY
			MOUSE SENSITIVITY
			AUDIO GAIN
			RECORD CONFIG
			TIME SETUP
			DATE
			TIME
	SYSTEM	GENERAL	NTP SERVER
			FORMAT
			SYNC PERIOD
			GMT
			DAYLIGHT
			EaZy
			ACCOUNT
			TOOLS
			LANGUAGE
			UPGRADE
	EVENT INFORMATION	GENERAL	NETWORK UPGRADE
			BACKUP CONFIG
			RESTORE CONFIG
			SYSTEM INFO
			BAUD RATE
			HOST ID
			R.E.T.R.
			AUTO KEY LOCK(S)
			CLEAR HDD
			RESET DEFAULT
	ADVANCED CONFIG	GENERAL	REMOTE CONTROL ID
			DEVICE TITLE
			SERIAL TYPE
			VIDEO FORMAT
			VERSION
			BACKUP DATA
			BACKUP LOG
			REGULAR REPORT
			QUICK SEARCH
			EVENT SEARCH
	ADVANCED CONFIG	GENERAL	HDD INFO
			EVENT LOG
			CAMERA
			BRIGHTNESS
			CONTRAST
			SATURATION
			HUE
			COV.
			REC
			TIME STAMP DISPLAY
	ADVANCED CONFIG	GENERAL	CHANNEL TITLE
			REC AUDIO
			DETECTION
			LS
			SS
			TS
			MOTION
			ALARM
			AREA
			PRIVACY MASK
	ADVANCED CONFIG	GENERAL	INTERNAL ALARM*
			ALERT
			EXT. ALERT
			INT. BUZZER
			KEY BUZZER
			VLOSS BUZZER
			MOTION BUZZER
			ALARM BUZZER
			HDD BUZZER
			ALARM DURATION (SEC)

	ALERT	HDD NEARLY FULL (GB) HDD OVERHEAT ALERT (°C)
	NETWORK	WAN E-MAIL DDNS PROTOCOL EaZy
	DISPLAY	FULL SCREEN DURATION QUAD SCREEN DURATION* DISPLAY COVERT HDD DISPLAY MODE DISPLAY OUTPUT COVERT UNLOCK IN SUPERVISOR MODE 3D DENOISE 2D DENOISE
	RECORD	MANUAL RECORD EVENT RECORD TIMER RECORD PRE-ALARM RECORD OVERWRITE KEEP DATA LIMIT (DAYS) RECORD CONFIG SUBSTREAM RESOLUTION
	DEVICES*	
	DCCS	
	IVS*	
	NOTIFY	PUSH VIDEO* PUSH STATUS MESSAGE MAIL VIDEO MAIL VIDEO FTP
	SCHEDULE SETTING	RECORD DETECTION ALARM IN ALARM OUT PUSH VIDEO BUZZER

*For selected models only

APPENDIX 6 EAZY NETWORKING

EaZy Networking is a cloud service to connect your devices to the Internet automatically through our free mobile app, EagleEyes, in a few steps without going through the complicated network setup including port forwarding.

Note: EaZy Networking is not a free service. We will initially provide 2GB data allowance (approx. 2185 minutes) for free. When 2GB is up, the network transmission will be down to 1 FPS. To restore the fluency of live view, users need to subscribe a data plan from EagleEyes, or configure the network settings by themselves.

To connect this recorder to the Internet without using EaZy Networking, get the network setup manual from www.surveillance-download.com/user/t204.swf.

Note: Data allowance is consumed only when the device access is made via Internet, 3G mobile network, and the network different from the device is used.

EaZy Networking could be configured via EagleEyes on an iOS / android device, or via Internet Explorer.

Before using this function, make sure:

- This DVR is connected to a switch or router, and the switch or router is ready for Internet connection.
- The network icon on the top right corner is  not .
- You have an iOS / Android mobile device with EagleEyes installed, or a PC / laptop with Internet Explorer installed.

A6.1 Via EagleEyes on iOS / Android Device

A7.1.1 Setup

Step1: Right-click to show the main menu, and select “NETWORK” → “WAN”. Set "NETWORK TYPE" to “DHCP”, and make sure the network icon on the top right corner is changed from  to .

Note: If the setting is made via the Setting Wizard, the network type will be automatically switched to DHCP.


ADVANCED CONFIG					
CAMERA DETECTION ALERT NETWORK DISPLAY RECORD DEVICES DCCS IVS NOTIFY	WAN	E-MAIL	DDNS	PROTOCOL	EaZy
	NETWORK TYPE	DHCP <input type="button" value="▼"/>			
IP	192.168.001.010				
GATEWAY	192.168.001.254				
NETMASK	255.255.255.000				
PRIMARY DNS	8.8.8.8				
SECONDARY DNS	168.95.1.1				
PORT	80				
CHECK INTERNET AVAILABILITY BY ADDRESS	www.google.com				
EXIT	MAC: 00:0E:53:EC:A7:B4				

Step2: In the same menu, select “EaZy”. Enable EaZy Networking, and leave this page open. You’ll need to scan the QR code later.

QUICK START		
GENERAL TIME SETUP DAYLIGHT EaZy	ENABLE EAZY NETWORKING	ON
	 000E532B8613	
EXIT		

Step3: Open EagleEyes on your mobile device, and select “...” on the top left corner in the address book. Then, click “”.

Step4: Click “Login” in the section of “Cloud” and register an account for “Cloud Service”. If you’ve got an account, please just log in.



Step5: Go back to the address book and click “+” to add a new device.

There are two methods to add new devices, “EaZy” and “Manual”.

Select “EaZy”, and choose the DVR icon to continue.



Step6: Click “” in the section of “MAC address” to open the QR code scan page, and scan the QR code on the DVR screen mentioned in Step2. The MAC address will be filled automatically.


Fill in the Captcha code manually, and click “Apply”.

Step7: Follow the on-screen instruction to finish the rest of the settings, and see if this device is added successfully to the address book as a cloud device.

At the same time, you'll be prompted to confirm if you want to remove the default user name and password.

- When the default user name and password are removed, you can **ONLY** use the user name and password of the cloud service to access this recorder locally and remotely. If you forget the user name and password of the cloud service, you could only reset the recorder and do all configurations again.
- When the default user name and password are kept, other people might be able to access this recorder if they know the default user name and password of this recorder.

Confirm if you want to keep the default account to continue, and return to the address book. You'll see the newly-added device in the address with a cloud icon on it.




Step8: Click the newly-added device and see if you could access successfully.

A6.1.2 Checking Remaining Data Allowance

Step1: Log into the cloud service.

Step2: Select “Details” to go to account information, and select “Available Data Allowance”.




A6.1.3 Sharing Cloud Device Access to Other Account(s)


Note: One cloud device could be shared up to 30 cloud accounts, but the access to the device might be failed because it is still restricted to the maximum online user setup of the device.

Step1: Log into the cloud service.

Step2: Select “Buddy” to go to the buddy sharing page. Then, choose the cloud device you want to share, and switch from “OFF” to “Share”.



Step3: Enter the cloud account or the E-mail registered by the account, and select “Add”.




Step4: Check again the account to which you want to share your cloud device, and select “Next” to confirm and continue.

Step5: Specify the access permission of the specified account, which account’s data allowance should be consumed after access successfully, and how long the account is allowed to stay after access successfully.


- Who should pay data allowance:

Who should pay data allowance	The order to consume data allowance
Me	The free data allowance provided by the device -> The additional data allowance shared to other account(s) by the owner -> The additional data allowance of the device's owner -> The data allowance shared to other account(s) by the buddy
Him / Her	The additional data allowance of the buddy -> The data allowance shared to other account(s) by the buddy

Note: When there's no data allowance to use, the network transmission will be down to 1 FPS. To restore the fluency of live view, users need to subscribe a data plan from EagleEyes, or configure the network settings by themselves.



Step6: Check again the configurations you made for the account to which you want to share your cloud device, and select “Share!” to confirm.



Step7: (Optional) Configure the data allowance shared to other accounts to use.

Step8: Return to the address book of EagleEyes. You'll see the device being shared is marked with an icon of two people.

A6.2 Via Internet Explorer on PC / Laptop

Note: EaZy Networking setup via a web browser is only available on Internet Explorer.

A7.2.1 Setup

Step1: Right-click to show the main menu, and select “NETWORK” → “WAN”. Set “NETWORK TYPE” to “DHCP”, and make sure the network icon on the top right corner is changed from to .

Note: If the setting is made via the Setting Wizard, the network type will be automatically switched to DHCP.

ADVANCED CONFIG						
CAMERA DETECTION ALERT NETWORK DISPLAY RECORD DEVICES DCCS IVS NOTIFY	WAN	E-MAIL	DDNS	PROTOCOL	EaZy	
	NETWORK TYPE					DHCP ▼
	IP	192.168.001.010				
	GATEWAY	192.168.001.254				
	NETMASK	255.255.255.000				
	PRIMARY DNS	8.8.8.8				
	SECONDARY DNS	168.95.1.1				
	PORT	80				
	CHECK INTERNET AVAILABILITY BY ADDRESS					www.google.com
EXIT	MAC: 00:0E:53:EC:A7:B4					


Step2: In the same menu, select “EaZy”. Enable EaZy Networking, and write down the MAC address starting with “000E53” under the QR code. You'll need it later.

QUICK START		
GENERAL TIME SETUP DAYLIGHT EaZy	ENABLE EAZY NETWORKING ON	
	 000E532B8613	
EXIT		

Step3: Open Internet Explorer on a PC / laptop, and enter <https://ez.eagleeyes.tw>.

In the login page, register an account for “Cloud Service”. If you’ve got an account, please just log in.


Note: Your PC must be connected to Internet.




Step4: For the first time to access this website, you’ll be prompted to install a plugin: **EaZy Control**. Please install this plugin to ensure the service works properly.

Note: If you’re not prompted to install the plugin, please lower the security level of Internet Explorer, and try to log into the cloud service again.

Step5: Click “+” to add a new device and you’ll be prompted to install a program, **EaZy Wizard**. Follow the instructions to install this program.




Step6: Enable EaZy Wizard, and click “Start” to go to the login page. Log into the cloud service.



Step7: Select the recorder picture, or choose “DVR / NVR” on the bottom right corner. Then, enter the MAC address you wrote down in Step2, and the security code.

Click “Apply” to continue.




Step8: When your device is found, you'll be directed to the next page to change the device title if you want.

Note: The device name changed here will be fixed and can't be changed later.

Click “Apply” to continue. You'll be prompted to confirm if you want to remove the default user name and password.

- When the default user name and password are removed, you can **ONLY** use the user name and password of the cloud service to access this recorder locally and remotely. If you forget the user name and password of the cloud service, you could only reset the recorder and do all configurations again.
- When the default user name and password are kept, other people might be able to access this recorder if they know the default user name and password of this recorder.

Confirm if you want to keep the default account, and click “Apply” to continue and return to the main page.




Step9: You'll see the newly-added device with a cloud icon on the main page. Click the device and see if you can access the device successfully.



A6.2.2 Checking Remaining Data Allowance

Step1: Log into the cloud service.

Step2: Select “Account Information” on the top right corner to go to account information, and select “Available Data Allowance”.




A6.2.3 Sharing Cloud Device Access to Other Account(s)


Note: One cloud device could be shared up to 30 cloud accounts, but the access to the device might be failed because it is still restricted to the maximum online user setup of the device.

Step1: Log into the cloud service.

Step2: Select “Buddy Share” to go to the buddy sharing page. Then, choose the tag “Your own devices”, and select “Share to Buddy”.




Step3: Choose the cloud device you want to share, and click “Next” to enter the cloud account or the E-mail registered by the account you want to share with. Then, select “Add”.



Step4: Check again the account to which you want to share your cloud device.

To add more accounts, select “Add”; to remove the existing account, select “Delete”; to continue buddy setup, select “Next”.

Step5: Specify the access permission of the specified account, which account's data allowance should be consumed after access successfully, and how long the account is allowed to stay after access successfully.



- Who should pay data allowance:


Who should pay data allowance	The order to consume data allowance
Me	The free data allowance provided by the device -> The additional data allowance shared to other account(s) by the owner -> The additional data allowance of the device's owner -> The data allowance shared to other account(s) by the buddy
Him / Her	The additional data allowance of the buddy -> The data allowance shared to other account(s) by the buddy

Note: When there's no data allowance to use, the network transmission will be down to 1 FPS. To restore the fluency of live view, users need to subscribe a data plan from EagleEyes, or configure the network settings by themselves.

Step6: Check again the configurations you made for the account to which you want to share your cloud device, and select "Share!" to continue.

Step7: (Optional) Configure the data allowance shared to other accounts to use.

Step8: Return to the main page. You'll see the device being shared is marked with an icon of two people.



A7.3 Cloud Icons



Device connection ok



Device being shared to you and connection ok



Device shared to other account and connection ok



Device connection failed



Device being shared to you and connection failed



Device shared to other account and connection failed